


# \*Please note Arrow under Coil on Valve for direction of Air Flow



*The Hose fittings are shown for representation.  
Straight/90 degrees can be interchanged depending  
on your application requirements.*